



# BIOFOG 200

Aerial surface disinfection system



**STERILIZATION**



## Description

BIOFOG 200 is a fogger machine. It allows the aerial surface disinfection\* through the issuance of a dry fog and ultra-thin.

All surfaces in contact with the air are so processed without human intervention.

The tank is made of polished stainless steel (autoclavable) 5 L capacity.

This large tank capacity allows the processing of rooms whose volume may reach up to 400 m<sup>3</sup>.

The accurate dosage of disinfectant ensures maximum optimization of product consumption.

The BIOFOG 200 unit is mounted on a rotating base allowing the diffusion of aerosol in a radius of 360° without any manipulation.

A scheduler allows to set the time of distribution of the aerosol.

Applications:

Bactericidal treatment, virucidal, fungicidal, sporicidal of surfaces

Hospitals: operating room, intensive care room, sterilization room

Pharmaceutical industry and laboratories: microbiology, solutions manufacturing.

**\*For the disinfection of surfaces the AM100.UV mobile air sanitizer can be coupled to the fog generator BIOFOG 200 (AM200.UV)**

## Specification

MODEL	BIOFOG200
Power supply	220/230V AC 50 or 60hz
Aerosol	Submicron size
Spread & reach	Distance 15,25m / height 7,60m
Treatment of 100 m <sup>2</sup>	400 ml disinfectant solution
Solution tank	5 litres stainless steel Gr 304
Intake air filter	2 layers for dust and fog separation
Space treatment	425 m <sup>3</sup>



ESSE3 srl, Via Garibaldi 30  
14022 Castelnuovo D.B. (AT)  
Tel +39 011 99 27 706  
Fax +39 011 99 27 506  
e-mail [esse3@chierinet.it](mailto:esse3@chierinet.it)  
web: [www.esse3.dreamgest.com](http://www.esse3.dreamgest.com)

